
CARE AND MAINTENANCE

WOOD CARE

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

TIMBER/ WOOD CARE

- Wood and frame surfaces require regular dusting.
- When cleaning is needed, use a damp cloth followed by a dry cloth.
- Remove liquid spills or dirt immediately from the frame and mechanism parts.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping

A
S
S
E
M
B
L
Y
I
N
S
T
R
U
C
T
I
O
N
S

CONGRATULATIONS

You are now the proud owner of a Side Table.
We are confident you will enjoy the comfort
and style of this new furniture.



IMPORTANT

Read this and other relevant instructions
before using the product. Keep this manual
for future reference.

SIDE TABLE ASSEMBLY INSTRUCTIONS

FITTING

I
Screws M6 X 30 = 12 pcs
(9 pcs for triangle table)




II
Allen key 4mm = 1 pc




PARTS


I
Table Top = 1 pc





II
Leg = 4 pcs
(3 pcs for triangle table)



STEP 1
Put table top on to a flat surface.



STEP 2
Put legs on to the table top, insert and tighten all the screws.



FINISHED

